

LEGEND

	EXISTING AC PATH / RAMP		PROPOSED CURB & GUTTER
	CENTERLINE		PROPOSED VERTICAL CURB
	EXISTING CURB & GUTTER		PROPOSED CONTOUR
	EXISTING CURB		PROPOSED STORM DRAIN LINE
	EXISTING ELECTRICAL LINE		EXISTING ELECTRICAL MANHOLE
	EXISTING SANITARY SEWER LINE		EXISTING ELECTRICAL BOX
	EXISTING STORM DRAIN LINE		EXISTING CATCH BASIN
	EXISTING TELEPHONE LINE		EXISTING MANHOLE
	EXISTING DOMESTIC WATER LINE		EXISTING ELECTROLIER
	EXISTING LAKE WATER LINE		EXISTING WATER VALVE
	EXISTING SEARSVILLE WATER LINE		EXISTING FIRE HYDRANT
	EXISTING STEAM & CONDENSATE LINE		EXISTING SIGN
	EXISTING CHILLED WATER LINE		EXISTING SURVEY CONTROL
	EXISTING STREET LIGHT LINE		DETAIL NUMBER DESIGNATION
	EXISTING COMMUNICATION LINE		PROPOSED CATCH BASIN
	EXISTING GAS LINE		PROPOSED ELECTROLIER
			PROPOSED OVERFLOW DRAIN

PROJECT NOTES

- THE BAY AREA AIR QUALITY MANAGEMENT DISTRICT (BAAQMD) HAS IDENTIFIED A SET OF FEASIBLE PM10 CONTROL MEASURES FOR ALL CONSTRUCTION ACTIVITIES. THESE CONTROL MEASURES, AS PREVIOUSLY REQUIRED IN THE PROGRAM EIR, SHALL BE ADHERED TO DURING ALL CONSTRUCTION ACTIVITIES.
  - WATER ALL ACTIVE CONSTRUCTION AREAS AT LEAST TWICE DAILY;
  - COVER ALL TRUCKS HAULING SOIL, SAND, AND OTHER LOOSE MATERIALS OR REQUIRE ALL TRUCKS TO MAINTAIN AT LEAST TWO FEET OF FREEBOARD;
  - PAVE, APPLY WATER THREE TIMES DAILY, OR APPLY (NON-TOXIC) SOIL STABILIZERS ON ALL UNPAVED ACCESS ROADS, PARKING AREAS AND STAGING AREAS AT CONSTRUCTION SITES;
  - SWEEP DAILY (WITH WATER SWEEPERS) ALL PAVED ACCESS ROADS, PARKING AREAS AND STAGING AREAS AT CONSTRUCTION SITES. THE USE OF DRY POWDER SWEEPING IS PROHIBITED;
  - SWEEP STREETS DAILY (WITH WATER SWEEPERS) IF VISIBLE SOIL MATERIAL IS CARRIED ONTO ADJACENT PUBLIC STREETS. THE USE OF DRY POWDER SWEEPING IS PROHIBITED;
  - HYDROSEED OR APPLY (NON-TOXIC) SOIL STABILIZERS TO INACTIVE CONSTRUCTION AREAS (PREVIOUSLY GRADED AREAS INACTIVE FOR TEN DAYS OR MORE);
  - ENCLOSE, COVER, WATER TWICE DAILY OR APPLY (NON-TOXIC) SOIL BINDERS TO EXPOSED STOCKPILES (DIRT,SAND);
  - LIMIT TRAFFIC SPEEDS ON UNPAVED ROADS TO 15 MPH;
  - INSTALL FIBER ROLLS, SANDBAGS OR OTHER EROSION CONTROL MEASURES TO PREVENT SILT RUNOFF TO PUBLIC ROADWAYS;
  - REPLANT VEGETATION IN DISTURBED AREAS AS QUICKLY AS POSSIBLE;
  - INSTALL WHEEL WASHERS FOR ALL EXISTING TRUCKS, OR WASH OFF TIRES OF TRACKS OF ALL TRUCKS AND EQUIPMENT LEAVING THE SITE; AND
  - SUSPEND ALL EXCAVATION AND GRADING ACTIVITY WHEN WINDS (INSTANTANEOUS GUSTS) EXCEED 25 MPH.
- ALL CONSTRUCTION CONTRACTORS SHALL PROPERLY MAINTAIN THE EQUIPMENT AND WHERE FEASIBLE, USE "CLEAN FUEL" EQUIPMENT AND EMISSIONS CONTROL TECHNOLOGY (EG., CNG FIRED ENGINES, CATALYTIC CONVERTERS, PARTICULATE TRAPS, ETC.). MEASURES TO REDUCE DIESEL FUEL EMISSION WOULD BE CONSIDERED FEASIBLE WHEN THEY ARE CAPABLE OF BEING USED ON EQUIPMENT WITHOUT INTERFERING SUBSTANTIALLY WITH EQUIPMENT PERFORMANCE.
- CONSTRUCTION MATERIALS AND FILL DIRT DELIVERED FROM OFF CAMPUS SHALL NOT BE DELIVERED BETWEEN THE HOURS OF 7:00 AM TO 9:00 AM AND 4:00 TO 6:00 PM ON WEEKDAYS.
- TRUCKS EXPORTING/IMPORTING FILL DIRT AND BUILDING MATERIALS FOR THE PROJECT SHALL USE APPROVED TRUCK ROUTES SHOWN IN THE 2000 GUP, AS DESIGNATED BY THE CITIES OF PALO ALTO AND MENLO PARK.
- THE WATER AND SANITARY UTILITIES SHOWN ON THESE PLANS ARE NOT PART OF THIS GRADING PERMIT AND ARE SHOWN FOR REFERENCE ONLY.
- GRADING WORK BETWEEN OCTOBER 15 AND APRIL 15 IS AT THE DISCRETION OF THE SANTA CLARA COUNTY GRADING OFFICIAL.
- THE OWNER AND PRIME CONTRACTOR ARE RESPONSIBLE FOR MAINTAINING PROJECT SITE ACCESS AND NEIGHBORHOOD ACCESS FOR EMERGENCY VEHICLES AND LOCAL RESIDENTS.
- PRIOR TO GRADING COMPLETION AND RELEASE OF BOND, ALL GRADED AREAS SHALL BE RESEEDDED IN CONFORMANCE WITH THE COUNTY GRADING ORDINANCE TO MINIMIZE THE VISUAL IMPACTS OF THE GRADED SLOPES AND REDUCE THE POTENTIAL FOR EROSION ON THE SUBJECT SITE.
- EROSION CONTROL PLAN IS A GUIDE AND SHALL BE AMENDED AS NECESSARY TO PREVENT EROSION AND ILLICIT DISCHARGES ON A YEAR ROUND BASIS, DEPENDING ON THE SEASON, WEATHER, AND FIELD CONDITIONS. EROSION CONTROL MEASURES IN ADDITION TO THOSE NOTED IN THE PERMITTED PLANS MAY BE NECESSARY. FAILURE TO INSTALL SITE AND SITUATIONALLY APPROPRIATE EROSION CONTROL MEASURES MAY RESULT IN VIOLATIONS, FINES AND A STOPPAGE OF WORK.
- THE DEVELOPER IS RESPONSIBLE FOR THE INSTALLATION OF THE WORK PROPOSED ON THE EROSION CONTROL PLANS. THE ENGINEER OF RECORD IS RESPONSIBLE FOR THE DESIGN OF THE EROSION CONTROL PLANS AND ANY MODIFICATIONS OF THE EROSION PLANS TO PREVENT ILLICIT DISCHARGES FROM THE SITE DURING CONSTRUCTION.
- THE CONSTRUCTION INSPECTOR MAY VERIFY THAT A VALID NOTICE OF INTENT (NOI) HAS BEEN ISSUED BY THE STATE AND AN UPDATED STORM WATER POLLUTION PREVENTION PLAN (SWPPP) IS AVAILABLE ON THE SITE.
- IN THE EVENT THAT PREVIOUSLY UNIDENTIFIED HISTORIC OR PREHISTORIC ARCHAEOLOGICAL RESOURCES ARE DISCOVERED DURING BUILDING CONSTRUCTION, THE CONTRACTOR SHALL CEASE WORK IN THE IMMEDIATE AREA AND THE COUNTY PLANNING OFFICE AND CAMPUS ARCHAEOLOGIST SHALL BE CONTACTED. AN INDEPENDENT QUALIFIED ARCHAEOLOGIST RETAINED BY THE COUNTY AT THE EXPENSE OF STANFORD SHALL ASSESS THE SIGNIFICANCE OF THE FIND AND MAKE MITIGATION RECOMMENDATIONS.
- THE CONTRACTOR SHALL FILE FOR AND OBTAIN BUILDING PERMITS FOR ALL STRUCTURES AND BRIDGES TO BE CONSTRUCTED, AND FOR ALL LIGHTING TO BE INSTALLED FOR THE PROJECT.
- THE PROJECT HAS BEEN CONDITIONED TO REQUIRE ALL TRUCK TRAVEL TO USE ONLY APPROVED AREA TRUCK ROUTES, AND ALL TRUCK TRAVEL, EITHER FOR EXCAVATING MATERIALS OR FOR TRANSPORTING CONSTRUCTION MATERIALS TO THE SITE, WOULD USE THESE ROUTES CONSISTENT WITH REQUIREMENTS UNDER THE GUP. FURTHER, THE PROJECT HAS BEEN CONDITIONED TO RESTRICT CONSTRUCTION MATERIAL DELIVERIES TO NON-PEAK HOURS.
- THE PROJECT MAY CREATE TEMPORARY NOISE IMPACTS DUE TO CONSTRUCTION ACTIVITIES AND CONSTRUCTION TRAFFIC. THE CONTRACTOR SHALL SUBMIT A TRAFFIC AND CONSTRUCTION MANAGEMENT PLAN. FURTHER, CONSTRUCTION ACTIVITIES SHALL BE LIMITED TO THE HOURS OF 7 AM AND 7 PM, MONDAY THROUGH SATURDAY, WITH NO CONSTRUCTION OCCURRING AFTER 7 PM OR ON SUNDAYS.

IMPERVIOUS / PERVIOUS SUMMARY  
EXISTING AREA

AREA	DESCRIPTION	C
3,985 SF	PERVIOUS	0.30
535 SF	IMPERVIOUS	0.85

PROPOSED AREA

ACRE	DESCRIPTION	C
1,040 SF	PERVIOUS	0.30
3,480 SF	IMPERVIOUS	0.85


INCREASE IN IMPERVIOUS AREA

INCREASE = PROPOSED IMPERVIOUS - EXISTING IMPERVIOUS  
3,480 - 535  
2,945SF

STANFORD UNIVERSITY  
OAK ROAD VEHICLE WASH STATION  
QUAD #14-S001

STANFORD, SANTA CLARA COUNTY  
CALIFORNIA

Proposed  
Site



CAMPUS VICINITY MAP

SCALE: NTS

UTILITY NOTES

- ALL EXISTING UTILITIES SHOWN ARE APPROXIMATE ONLY. IT IS THE CONTRACTOR'S RESPONSIBILITY TO LOCATE AND VERIFY THE ACTUAL LOCATION OF EXISTING UTILITIES PRIOR TO STARTING CONSTRUCTION.
- STANFORD ARBORIST SHALL BE PRESENT FOR ANY EXCAVATION/DEMOLITION WITHIN 10' OF EXISTING TREE DRIPLINES.
- REPLACE ALL VAULT/BOX COVERS AS NEEDED TO MEET H-20 LOADING IF LOCATION IS SUBJECT TO VEHICULAR TRAFFIC.
- CONTRACTOR SHALL ADJUST TO GRADE, AS NECESSARY ALL EXISTING SURFACE FEATURES SUCH AS UTILITY VALVES, VAULTS AND COVERS WHICH ARE IMPACTED BY THE PROPOSED IMPROVEMENTS.
- STORM AND SEWER VERTICAL ALIGNMENT TO GOVERN IN UTILITY CROSSING CONFLICTS. UTILITY TO CROSS ABOVE IF MINIMUM COVER CAN BE MAINTAINED; OTHERWISE CROSS BELOW AND MAINTAIN 12" MINIMUM VERTICAL SEPARATION BETWEEN UTILITY CROSSINGS.
- REFER TO TRENCH BACKFILL AND RESURFACING FOR ALL UTILITY TRENCHING.
- REPLACE CURB OR CURB AND GUTTER DISTURBED BY UTILITY CONSTRUCTION.
- STORM DRAIN: PVC SDR 35 FOR LINES SMALLER THAN 12". RCP CLASS III FOR 12" AND LARGER.

MISCELLANEOUS NOTES

- NOTIFY THE SOILS ENGINEER TWO (2) DAYS PRIOR TO COMMENCEMENT OF ANY GRADING WORK TO COORDINATE THE WORK IN THE FIELD WITH THE CONTRACTOR.
- EXISTING TREES SHALL BE PROTECTED IN PLACE BY FENCING DURING PERIOD OF CONSTRUCTION. TEMPORARY CRIBBING MAY BE NEEDED TO PROTECT SOILS AROUND TREES TO KEEP THEM FROM SLOUGHING AND EXPOSING ROOTS. CONTRACTOR TO GET OWNER APPROVAL TO CUT ROOTS LARGER THAN 3/4" DIAMETER.
- ALL WORK SHALL CONFORM TO STANFORD'S STANDARD DETAILS, SPECIFICATIONS, AND GUIDELINES.

SWPPP/NOI NOTE

- THIS PROJECT DISTURBS LESS THAN ONE (1) ACRE. THEREFORE THIS PROJECT DOES NOT NEED COVERAGE UNDER THE STATE CONSTRUCTION GENERAL PERMIT (I.E., FILE A NOTICE OF INTENT AND PREPARE A STORMWATER POLLUTION PREVENTION PLAN).

SHEET INDEX

C1.0	TITLE SHEET
PL1.1	GUP INFORMATION MAP
PL1.2	IMPERVIOUS AREAS EXHIBIT
C2.0	IMPROVEMENT PLAN
C3.0-C3.2	BEST MANAGEMENT PRACTICES
C4.0	STANFORD CONSTRUCTION DETAILS
C4.1	CONSTRUCTION DETAILS & CANOPY ELEVATION
C5.0	CONSTRUCTION SITE LOGISTICS & SAFETY PLAN

STRUCTURAL DRAWINGS TO BE PROVIDED BY OTHERS

PROJECT DESCRIPTION

CONSTRUCT VEHICLE WASH STATION WITH PREFABRICATED CANOPY.

PROJECT MANAGER

WILL HOWEKAMP  
340 BONAIR SIDING ROAD  
STANFORD, CA 94305  
(650) 213-6892  
howekamp@stanford.edu

ABBREVIATIONS

AB	AGGREGATE BASE	EX	EXISTING	PWR	POWER
AC	ASPHALT CONCRETE	FDC	FIRE DEPARTMENT CONNECTION	R	RIGHT OF CENTERLINE
AD	AREA DRAIN	FG	FINISHED GRADE	RCP	REINFORCED CONCRETE PIPE
ALT	ALTERNATE	FS	FIRE SERVICE	S	STATION
BCR	BEGIN CURB RETURN	GES	GREEN EARTH SCIENCE	SD	STORM DRAIN
BW	BEGINNING OF WALL	INV	INVERT	SED	SEE ELECTRICAL DRAWINGS
CO	CLEANOUT	KV	KILO - VOLT	SEQ	SCIENCE & ENGINEERING QUAD
CONC	CONCRETE	L	LEFT OF CENTERLINE	SIG	SIGNAL
CW	CHILLED WATER	MH	MANHOLE	SLD	SEE LANDSCAPE DRAWINGS
DW	DOMESTIC WATER	MIN	MINIMUM	SS	SANITARY SEWER
DI	DRAIN INLET	OC	ON CENTER	SSR	SOUTH SERVICE ROAD
DIP	DUCTILE IRON PIPE	OD	OVERFLOW DRAIN	SW	SEARSVILLE WATER
E	ELEVATION	PC	POINT ON CURVE	TC	TOP OF CURB
ECR	END CURB RETURN	PIV	POST INDICATOR VALVE	TEL	TELEPHONE
EG	EXISTING GRADE	PR	PROPOSED	TYP	TYPICAL
ELEC	ELECTRICAL	PRC	POINT OF REVERSE CURVE	TW	TOP OF WALL
EP	EDGE OF PAVEMENT	PVC	POLYVINYL CHLORIDE	VC	VERTICAL CURVE
EW	END OF WALL	PVI	POINT OF VERTICAL INTERSECTION	W	WATER
				WM	WATER METER

SITE DATA INFORMATION

GENERAL


APN:	142-05-045
PARCEL SIZE:	162.087 AC
DEVELOPMENT DISTRICT:	CAMPUS CENTER
LAND USE DESIGNATION:	ACADEMIC CAMPUS
SITE AREA:	0.09 AC
DEMOLITION AREA:	0.09 AC

PERCENTAGE OF SITE AREA:

BUILDING:	0%
PARKING/DRIVEWAYS:	2%
SIDEWALKS/STREETS:	8%
OUTSIDE STORAGE:	0%
LANDSCAPING:	90%
UNDEVELOPED:	0%
ESTIMATED CUT AND FILL:	
CUT:	140 CUBIC YARDS
FILL:	110 CUBIC YARDS

UNAUTHORIZED CHANGES & USES THE ENGINEER PREPARING THESE PLANS WILL NOT BE RESPONSIBLE FOR, OR LIABLE FOR, UNAUTHORIZED CHANGES TO OR USES OF THESE PLANS. ALL CHANGES TO THE PLANS MUST BE IN WRITING AND MUST BE APPROVED BY THE PREPARER OF THESE PLANS.

CALIFORNIA COUNCIL  
OF CIVIL ENGINEERS  
& LAND SURVEYORS



CONSTRUCTION CONTRACTOR AGREES THAT IN ACCORDANCE WITH GENERALLY ACCEPTED CONSTRUCTION PRACTICES, CONSTRUCTION CONTRACTOR WILL BE REQUIRED TO ASSUME SOLE AND COMPLETE RESPONSIBILITY FOR JOB SITE CONDITIONS DURING THE COURSE OF CONSTRUCTION OF THE PROJECT, INCLUDING SAFETY OF ALL PERSONS AND PROPERTY; THAT THIS REQUIREMENT SHALL BE MADE TO APPLY CONTINUOUSLY AND NOT BE LIMITED TO NORMAL WORKING HOURS; AND CONSTRUCTION CONTRACTOR FURTHER AGREES TO DEFEND, INDEMNIFY, AND HOLD DESIGN PROFESSIONAL HARMLESS FROM ANY AND ALL LIABILITY, REAL OR ALLEGED, IN CONNECTION WITH THE PERFORMANCE OF WORK ON THIS PROJECT, EXCEPTING LIABILITY ARISING FROM THE SOLE NEGLIGENCE OF DESIGN PROFESSIONAL.

CALIFORNIA COUNCIL  
OF CIVIL ENGINEERS  
& LAND SURVEYORS

OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY

TITLE SHEET

CALIFORNIA

SANTA CLARA COUNTY

STANFORD

BKF ENGINEERS  
1720 N. FIRST STREET  
SUITE 600  
SANTA CLARA, CA 95112  
(408) 462-9100  
www.bkf.com



Revisions

No.

Scale

Design: CJ

Drawn: CJ

Approved: DP

Lib. No. 20190701


Drawing Number:

C1.0


OF



\\bke\proj\2019\Stanford\_Station\_Wash\GIS\MapDocs\MapDoc-001.apr  
2/2/2023 10:51 AM  
BKF



**PROPOSED SITE**



BKF ENGINEERS  
1720 N. FIRST STREET  
SUITE 600  
SANTA CLARA, CA 95112  
(408) 462-9100  
www.bkf.com



**OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
GUP INFORMATION MAP**

CALIFORNIA


SANTA CLARA COUNTY

STANFORD

Revisions	
No.	
Date: 02/09/2023	
Scale: -	
Design: CJ	
Drawn: CJ	
Approved: DP	
Job No: 20190701	

Drawing Number:  
**PL1.1**  
OF





\\bke\proj\14-555\14-555\_VW.dwg  
03/09/2023 10:00 AM  
BKF ENGINEERS

APPLICANT: STANFORD UNIVERSITY

ROAD: OAK ROAD

COUNTY FILE NO.:

BKF ENGINEERS  
1730 N. FIRST STREET  
SUITE 600  
SANTA CLARA, CA 95112  
(408) 462-9100  
www.bkf.com



OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
IMPERVIOUS AREAS EXHIBIT

CALIFORNIA

SANTA CLARA COUNTY

STANFORD

Date	No.	Revisions
03/09/2023		
Scale: 1"=10'		
Design: CU		
Drawn: CU		
Approved: DP		
Job No: 20190701		

Drawing Number:

PL1.2

OF





NOTES

- SURFACE STRUCTURES, INCLUDING BUT NOT LIMITED TO, MANHOLES, WATER VALVE BOXES, CLEAN OUTS, ETC. SHALL BE BROUGHT TO FINISH GRADE AFTER PAVING IS COMPLETED.
- CONTRACTOR SHALL VERIFY ALL ELEVATIONS AND LOCATIONS OF EXISTING PIPES AND UTILITIES BEFORE EXCAVATION WORK OR MAKING ANY UTILITY CONNECTIONS.

LEGEND

- REINFORCED CONCRETE PAVING W/ #4 @ 18" O.C. (6" PCC / 6" CL II AB)
- PEDESTRIAN CONCRETE PAVING (6" PCC / 4" CL II AB)
- VEHICULAR ASPHALT PAVING (4" AC / 12" CL II AB)
- 12" WIDE FLAT COMPACTED SOIL AROUND CURB FOR CANOPY STRUCTURE
- EXISTING SPOT GRADE
- PROPOSED SPOT GRADE
- EXISTING SLOPE
- PROPOSED SLOPE
- SAWCUT
- SS SANITARY SEWER LINE
- DW DOMESTIC WATER LINE
- LW LAKE WATER LINE
- TP WATER LINE FROM TRAP PRIMER TO DRAIN INLET
- DI DRAIN INLET (SEE STANFORD STANDARD DETAIL CS-271)
- SSCO SANITARY SEWER CLEANOUT (SEE STANFORD STANDARD DETAIL CS-212)
- PV PAVEMENT
- FL FLOW LINE
- TC TOP OF CURB


3 SIGNAGE AND STRIPING PLAN




4 TREE CANOPY

PLUMBING FIXTURE SCHEDULE					
TAG	DESCRIPTION	MANUFACTURER	MODEL	DW	REMARKS
TP-1	TRAP PRIMER	ZURN	Z1022-XL	1/2"	MECHANICAL


PIPING MATERIAL SCHEDULE					
MARK	NAME	SIZE	MATERIALS	PIPE AND FITTING JOINTS	INSULATION
DW	DOMESTIC WATER	2" AND SMALLER	COPPER TYPE "L"	LEAD-FREE SOLDER OR PROPPRESS	-
SS	SANITARY SEWER	ALL	PVC SDR-26	BELL & SPIGOT	-
-	SS VENTS	ALL	NO-HUB CAST IRON OR DWV COPPER	CLAMP ALL FITTINGS	-




GRAPHIC SCALE



1 HORIZONTAL CONTROL AND UTILITY PLAN



2 GRADING PLAN



DATE: 03/09/2023  
DRAWN BY: J. L. LEE  
CHECKED BY: J. L. LEE  
APPROVED BY: J. L. LEE

OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
IMPROVEMENT PLAN



Revisions	No.	Date	By	Appr.
	1	03/09/2023	J. L. LEE	J. L. LEE

C2.0  
OF



BKF ENGINEERS  
7720 N. FIRST STREET  
SUITE 600  
SAN JOSE, CA 95132  
(408) 462-9100  
www.bkf.com




OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
BEST MANAGEMENT PRACTICES

CALIFORNIA

SANTA CLARA COUNTY

STANFORD



Project Information

Revisions		No.	Date
1		03/09/2023	
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			

OF



BMP-1


## Best Management Practices and Erosion Control Details Sheet 1

### County of Santa Clara

Source for Graphics: California Stormwater BMP Handbook, California Stormwater Quality Association, January 2003. Available from www.cabmphandbooks.com.


### 3 Stabilized Construction Entrance/Exit

CASQA Detail TC-1



### 1 Silt Fence


CASQA Detail SE-1



- NOTES
- Construct the length of each reach so that the change in base elevation along the reach does not exceed 1/3 the height of the linear barrier, in no case shall the reach length exceed 500'.
  - The last 8'-0" of fence shall be turned up slope.
  - Stake dimensions are nominal.
  - Dimension may vary to fit field condition.
  - Stakes shall be spaced at 8'-0" maximum and shall be positioned on downstream side of fence.
  - Stakes to overlap and fence fabric to fold around each stake one full turn. Secure fabric to stake with 4 staples.
  - Stakes shall be driven tightly together to prevent potential flow-through of sediment at joint. The tops of the stakes shall be secured with wire.
  - For end stake, fence fabric shall be folded around two stakes one full turn and secured with 4 staples.
  - Minimum 4 staples per stake. Dimensions shown are typical.
  - Cross barriers shall be a minimum of 1/3 and a maximum of 1/2 the height of the linear barrier.
  - Maintenance openings shall be constructed in a manner to ensure sediment remains behind silt fence.
  - Joining sections shall not be placed at sump locations.
  - Sandbag rows and layers shall be offset to eliminate gaps.

### 4 Velocity Dissipation Devices


CASQA Detail EC-10



\* Length per ABAG Design Standards

### 2 Silt Fence

CASQA Detail SE-1



#### STANDARD BEST MANAGEMENT PRACTICE NOTES

- Solid and Demolition Waste Management:** Provide designated waste collection areas and containers on site away from streets, gutters, storm drains, and waterways, and arrange for regular disposal. Waste containers must be watertight and covered at all times except when waste is deposited. Refer to Erosion & Sediment Control Field Manual, 4th Edition (page C-3) or latest.
- Hazardous Waste Management:** Provide proper handling and disposal of hazardous wastes by a licensed hazardous waste material hauler. Hazardous wastes shall be stored and properly labeled in sealed containers constructed of suitable materials. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-5 to C-6) or latest.
- Spill Prevention and Control:** Provide proper storage areas for liquid and solid materials, including chemicals and hazardous substances, away from streets, gutters, storm drains, and waterways. Spill control materials must be kept on site where readily accessible. Spills must be cleaned up immediately and contaminated soil disposed properly. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-7 to C-8, C-13 to C-14) or latest.
- Vehicle and Construction Equipment Service and Storage:** An area shall be designated for the maintenance, where on-site maintenance is required, and storage of equipment that is protected from stormwater run-on and runoff. Measures shall be provided to capture any waste oils, lubricants, or other potential pollutants and these wastes shall be properly disposed of off site. Fueling and major maintenance repair, and washing shall be conducted off-site whenever feasible. Refer to Erosion & Sediment Control Field Manual, 4th Edition (page C-9) or latest.
- Material Delivery, Handling and Storage:** In general, materials should not be stockpiled on site. Where temporary stockpiles are necessary and approved by the County, they shall be covered with secured plastic sheeting or tarp and located in designated areas near construction entrances and away from drainage paths and waterways. Barriers shall be provided around storage areas where materials are potentially in contact with runoff. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-11 to C-12) or latest.
- Handling and Disposal of Concrete and Cement:** When concrete trucks and equipment are washed on-site, concrete wastewater shall be contained in designated containers or in a temporary lined and watertight pit where wasted concrete can harden for later removal. If possible have concrete contractor remove concrete wash water from site. In no case shall fresh concrete be washed into the road right-of-way. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-15 to C-16) or latest.
- Pavement Construction Management:** Prevent or reduce the discharge of pollutants from paving operations, using measures to prevent run-on and runoff pollution and properly disposing of wastes. Avoid paving in the wet season and reschedule paving when rain is in the forecast. Residue from saw-cutting shall be vacuumed for proper disposal. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-17 to C-18) or latest.
- Contaminated Soil and Water Management:** Inspections to identify contaminated soils should occur prior to construction and at regular intervals during construction. Remediating contaminated soil should occur promptly after identification and be specific to the contaminant identified, which may include hazardous waste removal. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages C-19 to C-20) or latest.
- Sanitary/Septic Water Management:** Temporary sanitary facilities should be located away from drainage paths, waterways, and traffic areas. Only licensed sanitary and septic waste haulers should be used. Secondary containment should be provided for all sanitary facilities. Refer to Erosion & Sediment Control Field Manual, 4th Edition (page C-21) or latest.
- Inspection & Maintenance:** Areas of material and equipment storage sites and temporary sanitary facilities must be inspected weekly. Problem areas shall be identified and appropriate additional and/or alternative control measures implemented immediately, within 24 hours of the problem being identified.

#### STANDARD EROSION CONTROL NOTES

- Sediment Control Management:**
  - Tracking Prevention & Clean Up:** Activities shall be organized and measures taken as needed to prevent or minimize tracking of soil onto the public street system. A gravel or proprietary device construction entrance/exit is required for all sites. Clean up of tracked material shall be provided by means of a street sweeper prior to an approaching rain event, or at least once at the end of each workday that material is tracked, or more frequently as determined by the County Inspector. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages B-31 to B-33) or latest.
  - Storm Drain Inlet and Catch Basin Inlet Protection:** All inlets within the vicinity of the project and within the project limits shall be protected with gravel bags placed around inlets or other inlet protection. At locations where exposed soils are present, staked fiber rolls or staked silt fences can be used. Inlet filters are not allowed due to clogging and subsequent flooding. Refer to Erosion & Sediment Control Field Manual, 4th Edition (pages B-49 to B-51) or latest.
  - Storm Water Runoff:** No storm water runoff shall be allowed to drain in to the existing and/or proposed underground storm drain system or other above ground watercourses until appropriate erosion control measures are fully installed.
  - Dust Control:** The contractor shall provide dust control in graded areas as required by providing wet suppression or chemical stabilization of exposed soils, providing for rapid clean up of sediments deposited on paved roads, furnishing construction road entrances and vehicle wash down areas, and limiting the amount of areas disturbed by clearing and earth moving operations by scheduling these activities in phases.
  - Stockpiling:** Excavated soils shall not be placed in streets or on paved areas. Borrow and temporary stockpiles shall be protected with appropriate erosion control measures (tarps, straw bales, silt fences, etc.) to ensure silt does not leave the site or enter the storm drain system or neighboring watercourse.
- Erosion Control:** During the rainy season, all disturbed areas must include an effective combination of erosion and sediment control. It is required that temporary erosion control measures are applied to all disturbed soil areas prior to a rain event. During the non-rainy season, erosion control measures must be applied sufficient to control wind erosion at the site.
- Inspection & Maintenance:** Disturbed areas of the Project's site, locations where vehicles enter or exit the site, and all erosion and sediment controls that are identified as part of the Erosion Control Plans must be inspected by the Contractor before, during, and after storm events, and at least weekly during seasonal wet periods. Problem areas shall be identified and appropriate additional and/or alternative control measures implemented immediately, within 24 hours of the problem being identified.
- Project Completion:** Prior to project completion and signoff by the County Inspector, all disturbed areas shall be reseeded, planted, or landscaped to minimize the potential for erosion on the subject site.
- It shall be the Owner's/Contractor's responsibility to maintain control of the entire construction operation and to keep the entire site in compliance with the erosion control plan.
- Erosion and sediment control best management practices shall be operable year round or until vegetation is fully established on landscaped surfaces.



Figure 1: Details of the channel trench. The figure consists of six sub-diagrams:

- INITIAL CHANNEL ANCHOR TRENCH NTS**: A cross-section showing a trench with a 6" width and a 12" depth.
- TERMINAL SLOPE AND CHANNEL ANCHOR TRENCH NTS**: A cross-section showing a trench with a 6" width and a 12" depth, with a slope of 12" vertical to 6" horizontal.
- ISOMETRIC VIEW NTS**: A 3D perspective view of the trench and its connection to a main pipe. It shows a 3" overlap at the bottom, a check slot at 25-30" intervals, and a stake at 3' to 5' intervals.
- INTERMITTENT CHECK SLOT NTS**: A cross-section showing a trench with a 6" width and a 6" depth.
- LONGITUDINAL ANCHOR TRENCH NTS**: A cross-section showing a trench with a 4" width and a 4" depth, with a 4" x 4" anchor shoe.
- A detail view of the anchor shoe showing a 4" x 4" dimension.

NOTES:

1. Check slots to be constructed per manufacturers specifications.
2. Staking or stapling layout per manufacturers specifications.
3. Install per manufacturer's recommendations

4' 6" X 6" anchor trench

Berm

Mats/blankets should be installed vertically downslope.

6" Slope Max.

2' to 3' overlap

6" Strip Splice

12"

Filter cloth 4' above source of water

Water table

Non-woven geotextile filter fabric under typical treatment.

ISOMETRIC VIEW  
TYPICAL SLOPE  
SOIL STABILIZATION  
NTS

WET SLOPE LINING  
NTS

NOTES:

1. Slope surface shall be free of rocks, clods, sticks and grass. Mats/blankets shall have good soil contact.
2. Lay blankets loosely and stake or staple to maintain direct contact with the soil. Do not stretch.
3. Install per manufacturer's recommendations

The image contains two technical drawings of wash structures, labeled SECTION A-A and SECTION B-B.

**SECTION A-A**  
NOT TO SCALE

This cross-section shows a layer of crushed aggregate greater than 3" but smaller than 6" on top of corrugated steel panels. Below the panels is a filter fabric, and the original ground is shown at the bottom. A dimension line indicates a minimum depth of 12" unless otherwise specified by a soils engineer.

**SECTION B-B**  
NTS

This cross-section shows a layer of crushed aggregate greater than 3" but smaller than 6" on top of a filter fabric. Below the filter fabric is the original ground. A dimension line indicates a minimum depth of 12" unless otherwise specified by a soils engineer.

**Typical TIRE WASH**  
NOT TO SCALE

This plan view shows a paved roadway with an existing grade leading into a wash structure. The wash structure consists of a series of parallel wash racks. A ditch to the right carries runoff to a sediment trapping device. A water supply and hose connection is shown at the entrance. Points A and B are marked at the ends of the wash racks.

**NOTE:**  
Many designs can be field fabricated, or fabricated units may be used.

NOTE:  
Many designs can be field fabricated, or fabricated units may be used.

The drawing consists of two parts: a plan view of a slope and a cross-sectional detail of an entrenchment.

**Top View (Typical Fiber Roll Installation):** This view shows a slope with two fiber rolls installed along level contours. The rolls are labeled "Fiber rolls". A note states: "Note: Install fiber roll along a level contour." The vertical spacing between the rolls is indicated as "Vertical spacing measured along the face of the slope varies between 10' and 20'". The spacing between the rolls is labeled "4' max". The rolls are shown as cylindrical objects with a textured surface.

**Bottom View (Entrenchment Detail):** This view shows a cross-section of an entrenchment. A fiber roll is installed along the slope, labeled "Fiber roll 8' min". The slope is labeled "Slope varies". The width of the entrenchment is labeled "2' min" and "2' max". The depth of the entrenchment is labeled "12' min". The bottom of the entrenchment is reinforced with "3/4\" x 3/4\" wood stakes max 4' spacing".

**Labels and Dimensions:**

- Fiber rolls
- Note: Install fiber roll along a level contour.
- Vertical spacing measured along the face of the slope varies between 10' and 20'
- 4' max
- Install a fiber roll near slope where it transitions into a steeper slope
- TYPICAL FIBER ROLL INSTALLATION
- N.T.S.
- Slope varies
- Fiber roll 8' min
- 2' min
- 2' max
- 12' min
- 3/4" x 3/4" wood stakes max 4' spacing
- ENTRENCHMENT DETAIL
- N.T.S.

ENTRENCHMENT DETAIL  
N.T.S.

DI PROTECTION – TYPE 4  
NOT TO SCALE

TYPICAL PROTECTION FOR INLET ON GRADE

NOTES:

1. Intended for short-term use.
2. Use to inhibit non-storm water flow.
3. Allow for proper maintenance and cleanup.
4. Bags must be removed after adjacent operation is completed.
5. Not applicable in areas with high silts and clays without filter fabric.

The drawing consists of two parts: a cross-section and a plan view.

**Section A-A:** This view shows a cross-section of the drainage system. It features a central "Drain inlet" with a "1:1 slope" on either side. Above the inlet is a "Geotextile Blanket". To the left, a "Stabilize area and grade uniformly around perimeter" is indicated. A note states: "Notes: Remove sediment before reaching one-third full." Dimensions include a "3 Min" depth on the left, a "4'" width at the base, and a "12" Min" to "24" Max" height on the right. A "Silt fence Per SE-01" is shown on the right side.

**Plan:** This view shows the top-down layout of the drainage system. It is a square basin with a central "Drain inlet" and a "Rock filter (use if flow is concentrated)". The basin is surrounded by a "Geotextile Blanket" and a "Silt fence Per SE-01". Arrows indicate "Sheet flow" entering from the left and "Concentrated flow" entering from the top. A note indicates: "Edge of sediment trap".

**DI PROTECTION TYPE 2**  
NOT TO SCALE

**Notes**

1. For use in cleared and grubbed and in graded areas.
2. Shape basin so that longest inflow area faces longest length of trap.
3. For concentrated flows, shape basin in 2:1 ratio with length oriented towards direction of flow.

Notes

1. For use in cleared and grubbed and in graded areas.
2. Shape basin so that longest inflow area faces longest length of trap.
3. For concentrated flows, shape basin in 2:1 ratio with length oriented towards direction of flow.

MIN

VARIES

10 MIL PLASTIC LINING

STAKE (TYP)

B

STRAW BALE (TYP)

PLAN

NOT TO SCALE

TYPE "ABOVE GRADE" WITH STRAW BALES

2"

4"

1/8" DIA STEEL WIRE

STAPLE DETAIL

PLYWOOD 48" X 24" PAINTED WHITE

CONCRETE WASHOUT SIGN DETAIL

BLACK LETTERS 6" HEIGHT

0.5" LAG SCREWS

WOOD POST 3" X 3" X 8"

CONCRETE WASHOUT (OR EQUIVALENT)

STAPLES (2 PER BALE)

10 MIL PLASTIC LINING

BINDING WIRE

STRAW BALE

NATIVE MATERIAL (OPTIONAL)

WOOD OR METAL STAKES (2 PER BALE)

NOTES

1. ACTUAL LAYOUT DETERMINED IN FIELD.
2. THE CONCRETE WASHOUT SIGN SHALL BE INSTALLED WITHIN 30 FT. OF THE TEMPORARY CONCRETE WASHOUT FACILITY.

SECTION B-B

NOT TO SCALE

NOTES

1. ACTUAL LAYOUT DETERMINED IN FIELD.
2. THE CONCRETE WASHOUT SIGN SHALL BE INSTALLED WITHIN 30 FT. OF THE TEMPORARY CONCRETE WASHOUT FACILITY.

## Project Information



## BMP-2



## General Construction and Site Supervision

Best Management Practices for Construction



Who should use this brochure?

- General contractors
- Site supervisors
- Inspectors
- Home builders
- Developers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### General Principles

- Keep an orderly site and ensure good housekeeping practices are used.
- Maintain equipment properly.
- Use materials when they are not in use.
- Keep materials away from streets, storm drains and drainage channels.
- Ensure dust control water doesn't leave site or discharge to storm drains.

##### Advance Planning To Prevent Pollution

- Schedule excavation and grading activities for dry weather periods. To reduce soil erosion, plant temporary vegetation or place other erosion controls before rain begins. Use the Erosion and Sediment Control Manual for more information on the Regional Water Quality Control Board, as a reference.
- Control the amount of runoff crossing your site (especially during excavation) by using berms or temporary or permanent drainage ditches to divert water flow around the site. Reduce

### Storm Drain Pollution from Construction Activities

Construction sites are common sources of storm water pollution. Materials and wastes that blow or wash into a storm drain, gutter, or street have a direct impact on local creeks and the Bay.

**As a contractor, or site supervisor, owner or operator of a site, you may be responsible for any environmental damage caused by your subcontractors or employees.**

stormwater runoff velocities by constructing temporary check dams or berms where appropriate.

- Train your employees and subcontractors. Make these brochures available to everyone who works on the construction site. Inform subcontractors about the stormwater requirements and their own responsibilities. Use Blueprint for a Clean Bay, a construction best management practices guide available from the Santa Clara Valley Urban Runoff Pollution Prevention Program, as a reference.

##### Good Housekeeping Practices

- Designate one area of the site for auto parking, vehicle refueling, and routine equipment maintenance. The designated area should be well away from streams or storm drain inlets, bermed if necessary. Make major repairs off site.
- Keep materials out of the rain - prevent runoff contamination at the source. Cover exposed piles of soil or construction materials with plastic sheeting or temporary roofs. Before it rains, sweep and remove materials from surfaces that drain to storm drains, creeks, or channels.
- Keep pollutants off exposed surfaces. Place trash cans and recycling receptacles around the site to minimize litter.

- Clean up leaks, drips and other spills immediately so they do not contaminate soil or groundwater or leave residue on paved surfaces. Use dry cleanup methods whenever possible. If you must use water, use just enough to keep the dust down.
- Cover and maintain dumpsters. Check frequently for leaks. Place dumpsters under roofs or cover with tarps or plastic sheeting secured around the outside of the dumpster. Never clean out a dumpster by hosing it down on the construction site.
- Place portable toilets away from storm drains. Make sure portable toilets are in good working order. Check frequently for leaks.

##### Materials/Waste Handling


- Practice Source Reduction - minimize waste when you order materials. Order only the amount you need to finish the job.
- Use recyclable materials whenever possible. Arrange for pick-up of recyclable materials such as concrete, asphalt, scrap metal, solvents, degreasers, cleared vegetation, paper, rock, and vehicle maintenance materials such as used oil, antifreeze, batteries, and tires.
- Dispose of all wastes properly. Many construction materials and wastes, including solvents, water-based paint, vehicle fluids, broken asphalt and concrete, wood, and cleared vegetation can be recycled. (See the reference list of recyclers in Blueprint for a Clean Bay.) Materials that cannot be recycled must be taken to an appropriate landfill or disposed of as hazardous waste. Never bury waste materials or leave them in the street or near a creek or stream bed.

##### Permits

- In addition to local grading and building permits, you will need to obtain coverage under the State's General Construction Activity Stormwater Permit if your construction site's disturbed area totals 5 acres or more. Information on the General Permit can be obtained from the Regional Water Quality Control Board.

## Heavy Equipment Operation

Best Management Practices for the Construction Industry



Who should use this brochure?

- Vehicle and equipment operators
- Site supervisors
- General contractors
- Home builders
- Developers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### Site Planning and Preventive Vehicle Maintenance

- Designate one area of the construction site, well away from streams or storm drain inlets, for auto and equipment parking, refueling, and routine vehicle and equipment maintenance. Contain the area with berms, sand bags, or other barriers.
- Designate one area of the construction site, well away from streams or storm drain inlets, for auto and equipment parking, refueling, and routine vehicle and equipment maintenance. Contain the area with berms, sand bags, or other barriers.

### Stormwater Pollution from Heavy Equipment on Construction Sites

Poorly maintained vehicles and heavy equipment that leak fuel, oil, antifreeze or other fluids on the construction site are common sources of storm drain pollution. Prevent spills and leaks by isolating equipment from runoff channels, and by watching for leaks and other maintenance problems. Remove construction equipment from the site as soon as possible.

- Maintain all vehicles and heavy equipment. Inspect frequently for and repair leaks.

- Perform major maintenance, repair jobs, and vehicle and equipment washing off site where cleanup is easier.

- If you must drain and replace motor oil, radiator coolant, or other fluids on site, use dirt mats or drop cloths to catch drips and spills. Collect all spent fluids, store in separate containers, and properly dispose as hazardous waste (recycle whenever possible).

- Do not use diesel oil to lubricate equipment parts, or clean equipment. Use only water for any onsite cleaning.

- Cover exposed fifth wheel hitches and other oily or greasy equipment during rain events.

### Spill Cleanup

- Clean up spills immediately when they happen.

- Never hose down "dirty" pavement or impermeable surfaces where fluids have spilled. Use dry cleanup methods (absorbent materials, cat litter, and/or rags) whenever possible and properly dispose of absorbent materials.

- Sweep up spilled materials immediately. Never attempt to wash them away with water, or bury them.

- Use as little water as possible for dust control. Ensure water used doesn't leave silt or discharge to storm drains.

- Clean up spills on dirt areas by digging up and properly disposing of contaminated soil.

- Report significant spills to the appropriate local spill response agencies immediately. (See reverse side of brochure for telephone numbers.)

- If the spill poses a significant hazard to human health and safety, property or the environment, you must also report it to the State Office of Emergency Services (see reverse).

## Roadwork and Paving

Best Management Practices for the Construction Industry



Who should use this brochure?

- Road crews
- Driveways/sidewalk/parking lot construction crews
- Seal coat contractors
- Operators of grading equipment, paving machines, dump trucks, concrete mixers
- Construction inspectors
- General contractors
- Home builders
- Developers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our creeks and bays and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### General Business Practices

- Develop and implement erosion/sediment control plans for roadway embankments.
- Schedule excavation and grading work during dry weather.
- Check for and repair leaking equipment.
- Perform major equipment repairs at designated areas in your maintenance yard, where cleanup is easier. Avoid performing equipment repairs at construction sites.

### Storm Drain Pollution from Roadwork

Road paving, surfacing, and pavement removal happen right in the street, where there are numerous opportunities for asphalt, saw-cut slurry, or excavated material to illegally enter storm drains. Extra planning is required to store and dispose of materials properly and guard against pollution of storm drains, creeks, and the Bay.

- When refueling or when vehicle/equipment maintenance must be done on site, designate a location away from storm drains and creeks.
- Cover and seal catch basins and manholes when applying seal coat, slurry seal, fog seal, or similar materials.
- Protect drainage ways by using earth dikes, sandbags, or other controls to divert or trap and filter runoff.
- Never wash excess material from exposed-aggregate concrete or similar treatments into a street or storm drain. Collect and recycle, or dispose to dirt area.

##### During Construction

- Avoid paving and seal coating in wet weather, or when rain is forecast, to prevent fresh materials from contacting stormwater runoff.
- Cover and seal catch basins and manholes when applying seal coat, slurry seal, fog seal, or similar materials.
- Protect drainage ways by using earth dikes, sandbags, or other controls to divert or trap and filter runoff.
- Never wash excess material from exposed-aggregate concrete or similar treatments into a street or storm drain. Collect and recycle, or dispose to dirt area.

- Cover stockpiles (asphalt, sand, etc.) and other

## Fresh Concrete and Mortar Application

Best Management Practices for the Construction Industry



Who should use this brochure?

- Masons and bricklayers
- Sidewalk construction crews
- Patio construction workers
- Construction inspectors
- General contractors
- Home builders
- Developers
- Concrete delivery/pumping workers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.



### Storm Drain Pollution from Fresh Concrete and Mortar Applications

Fresh concrete and cement-related mortars that wash into lakes, streams, or estuaries are toxic to fish and the aquatic environment. Disposing of these materials to the storm drains or creeks can block storm drains, cause serious problems, and is prohibited by law.

#### Doing the Job Right

##### General Business Practices

- Wash out concrete mixers only in designated wash-out areas in your yard, away from storm drains and waterways, where the water will flow into a temporary waste pit in a dirt area. Let water percolate through soil and dispose of settled, hardened concrete as garbage. Whenever possible, recycle washout by pumping back into mixers for reuse.
- Wash out chutes onto dirt areas at site that do not flow to streets or drains.
- Always store both dry and wet materials under cover, protected from rainfall and runoff and away from storm drains or waterways. Protect dry materials from wind.
- Secure bags of cement after they are open. Be sure to keep wind-blown cement powder away from streets, gutters, storm drains, rainfall, and runoff.
- Do not use diesel fuel as a lubricant on concrete forms, tools, or trailers.

## Landscaping, Gardening, and Pool Maintenance

Best Management Practices for the Construction Industry



Who should use this brochure?

- Landscapers
- Gardeners
- Swimming pool/spa service and repair workers
- General contractors
- Home builders
- Developers
- Homeowners

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### General Business Practices

- Protect stockpiles and landscaping materials from wind and rain by storing them under tarps or secured plastic sheeting.
- Store pesticides, fertilizers, and other chemicals indoors or in a shed or storage cabinet.
- Schedule grading and excavation projects during dry weather.
- Use temporary check dams or ditches to divert runoff away from storm drains.
- Protect storm drains with sandbags or other sediment controls.
- Revegetation is an excellent form of erosion control for any site.

### Storm Drain Pollution from Landscaping and Swimming Pool Maintenance

Many landscaping activities expose soils and increase the likelihood that rain and garden chemicals will run off into the storm drains during irrigation or when it rains. Swimming pool water containing chlorine and copper-based algaecides should never be discharged to storm drains. These chemicals are toxic to aquatic life.

##### Landscaping/Garden Maintenance

- Use pesticides sparingly, according to instructions on the label. Rinse empty containers, and use insecticide as product. Dispose of rinsed, empty containers in the trash. Dispose of unused pesticides as hazardous waste.
- Collect lawn and garden clippings, pruning waste, and tree trimmings. Chip if necessary, and compost.
- On communities with curbside pick-up of yard waste, place clippings and pruning waste at the curb in approved bags or containers. Or, take to a landfill that composts yard waste. No curbside pickup of yard waste is available for commercial properties.
- Never discharge pool or spa water to a street or storm drain; discharge to a sanitary sewer cleanout.
- If possible, when emptying a pool or spa, let chlorine dissipate for a few days and then recycle/reuse water by draining it gradually onto a landscaped area.
- Do not use copper-based algaecides. Control algae with chlorine or other alternatives, such as sodium bromide.

##### Filter Cleaning

- Never clean a filter in the street or near a storm drain. Rinse cartridge and diatomaceous earth filters onto a dirt area, and place filter residue into soil. Dispose of spent diatomaceous earth in the garbage.
- In San Jose, leave yard waste for curbside recycling pickup in piles in the street. 18 inches from the curb and completely out of the flow line to any storm drain.

### Pool/Fountain/Spa Maintenance

##### Draining pools or spas

- When the time to drain a pool, spa, or fountain, please be sure to call your local wastewater treatment plant before you start for further guidance on flow rate restrictions, backflow prevention, and handling special cleaning waste (such as acid wash). Discharge flows should be kept to the low levels typically possible through a garden hose. Higher flow rates may be prohibited by local ordinance.

- Never discharge pool or spa water to a street or storm drain; discharge to a sanitary sewer cleanout.

- If possible, when emptying a pool or spa, let chlorine dissipate for a few days and then recycle/reuse water by draining it gradually onto a landscaped area.

- Do not use copper-based algaecides. Control algae with chlorine or other alternatives, such as sodium bromide.

- Never clean a filter in the street or near a storm drain. Rinse cartridge and diatomaceous earth filters onto a dirt area, and place filter residue into soil. Dispose of spent diatomaceous earth in the garbage.

- In San Jose, leave yard waste for curbside recycling pickup in piles in the street. 18 inches from the curb and completely out of the flow line to any storm drain.

## Earth-Moving and Dewatering Activities

Best Management Practices for the Construction Industry



Who should use this brochure?

- Buildozers, back hoe, and grading machine operators
- Dump truck drivers
- Site supervisors
- General contractors
- Home builders
- Developers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### General Business Practices

- Schedule excavation and grading work during dry weather.
- Perform major equipment repairs away from the job site.
- When refueling or vehicle/equipment maintenance must be done on site, designate a location away from storm drains.
- Do not use diesel oil to lubricate equipment parts, or clean equipment.

### Storm Drain Pollution from Earth-Moving Activities and Dewatering

Soil excavation and grading operations loosen large amounts of soil that can flow or blow into storm drains when handled improperly. Sediments in runoff can clog storm drains, smother aquatic life, and destroy habitats in creeks and the Bay. Effective erosion control practices reduce the amount of runoff crossing a site and slow the flow with check dams or roughened ground surfaces. Contaminated groundwater is a common problem in the Santa Clara Valley. Depending on soil types and site history, groundwater pumped from construction sites may be contaminated with toxics (such as oil or solvents) or laden with sediments. Any of these pollutants can harm wildlife in creeks or the Bay, or interfere with wastewater treatment plant operation.

Discharging sediment-laden water from a dewatering site into any water of the state without treatment is prohibited.

##### Practices During Construction

- Remove existing vegetation only when absolutely necessary. Plant temporary vegetation for erosion control on slopes or where construction is not immediately planned.
- Protect downslope drainage courses, streams, and storm drains with wattles, or temporary drainage swales. Use check dams or ditches to divert runoff around excavations. Refer to the Regional Water Quality Control Board's Erosion and Sediment Control Field Manual for proper erosion and sediment control measures.
- Cover stockpiles and excavated soil with secured tarps or plastic sheeting.

### Dewatering Operations

#### 1. Check for Toxic Pollutants

- Check for odors, discoloration, or an oily sheen on groundwater.
- Call your local wastewater treatment agency and ask whether the groundwater must be tested.
- If contamination is suspected, have the water tested by a certified laboratory.
- Depending on the test results, you may be allowed to discharge pumped groundwater to the storm or Ocean (if no sediments present) or sanitary sewer. OR, you may be required to collect and haul pumped groundwater off-site for treatment and disposal at an appropriate treatment facility.

#### 2. Check for Sediment Levels

- If the water is clear, the pumping time is less than 24 hours, and the flow rate is less than 20 gallons per minute, you may pump water to the street or storm drain.
- If the pumping time is more than 24 hours and the flow rate greater than 20 gpm, call your local wastewater treatment plant for guidance.
- If the water is not clear, solids must be filtered or settled out by pumping to a settling tank prior to discharge. Options for filtering include: Pumping through a perforated pipe sure, part way into a small pit filled with gravel.
- Pumping from a bucket placed below water level using a submersible pump.
- Pumping through a filtering device such as a swimming pool filter or filter fabric wrapped around end of suction pipe.
- When discharging to a storm drain, protect the inlet using a barrier of burlap bags filled with drain rock, or cover inlet with filter fabric anchored under the grate. OR pump water through a grassy swale prior to discharge.

### Small Business Hazardous Waste Disposal Program

## Painting and Application of Solvents and Adhesives

Best Management Practices for the Construction Industry



Who should use this brochure?

- Homeowners
- Painters
- Paperhangers
- Plasterers
- Graphic artists
- Dry wall crews
- Floor covering installers
- General contractors
- Home builders
- Developers

### Preventing Pollution: It's Up to Us

In the Santa Clara Valley, storm drains transport water directly to local creeks and San Francisco Bay without treatment. Stormwater pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or bayslands. Some common sources of this pollution include spilled oil, fuel, and fluids from vehicles and heavy equipment, construction debris, sediment created by erosion, landscaping runoff containing pesticides or weed killers, and materials such as used motor oil, antifreeze, and paint products that people pour or spill into a street or storm drain.

Thirteen valley municipalities have joined together with Santa Clara County and the Santa Clara Valley Water District to educate local residents and businesses and fight stormwater pollution. Join us, by following the practices described in this pamphlet.

#### Doing the Job Right

##### Handling Paint Products

- Keep all liquid paint products and wastes away from the gutter, street, and storm drains. Liquid residues from paints, thinners, solvents, glues, and cleaning fluids are hazardous wastes and must be disposed of at a hazardous waste collection facility (contact your local stormwater program listed on the back of this brochure).
- When thoroughly dry, empty paint cans, used brushes, rags, and drop cloths may be disposed of as garbage in a sanitary landfill. Empty, dry paint cans also may be recycled as metal.
- When painting or cleaning buildings constructed before 1978 can contain high amounts of lead, even if paint chips are not present. Before you begin stripping paint or cleaning pre-1978 building exteriors with water under high pressure, test paint for lead by taking paint scrapings to a local laboratory. See Yellow Pages for a state-certified laboratory.
- If there is a loose paint on the building, or if the paint tests positive for lead, lock storm drains. Check with the wastewater treatment plant to determine whether you may discharge water to the sanitary sewer, or if you must send it offsite for disposal as hazardous waste.

### Storm Drain Pollution from Paints, Solvents, and Adhesives

All paints, solvents, and adhesives contain chemicals that are harmful to wildlife in local creeks, San Francisco Bay, and the Pacific Ocean. Toxic chemicals may come from liquid or solid products or from cleaning residues or rags. Paint material and wastes, adhesives and cleaning fluids should be recycled when possible, or disposed of properly to prevent these materials from flowing into storm drains and watercourses.

#### Doing the Job Right

##### Handling Paint Products


- Keep all liquid paint products and wastes away from the gutter, street, and storm drains. Liquid residues from paints, thinners, solvents, glues, and cleaning fluids are hazardous wastes and must be disposed of at a hazardous waste collection facility (contact your local stormwater program listed on the back of this brochure).
- When thoroughly dry, empty paint cans, used brushes, rags, and drop cloths may be disposed of as garbage in a sanitary landfill. Empty, dry paint cans also may be recycled as metal.
- When painting or cleaning buildings constructed before 1978 can contain high amounts of lead, even if paint chips are not present. Before you begin stripping paint or cleaning pre-1978 building exteriors with water under high pressure, test paint for lead by taking paint scrapings to a local laboratory. See Yellow Pages for a state-certified laboratory.
- If there is a loose paint on the building, or if the paint tests positive for lead, lock storm drains. Check with the wastewater treatment plant to determine whether you may discharge water to the sanitary sewer, or if you must send it offsite for disposal as hazardous waste.

### Painting Cleanup

- Never clean brushes or rags, paint containers into a street, gutter, storm drain, French drain, or stream.
- For water-based paints, paint out brushes to the extent possible, and rinse into a drain that goes to the sanitary sewer. Never pour paint down a storm drain.
- For oil-based paints, paint out brushes to the extent possible and clean with thinner or solvent in a proper container. Filter and reuse thinners and solvents. Dispose of excess liquids and residue as hazardous waste.

#### Paint Removal

- Paint chips and dust from non-hazardous dry stripping and sand blasting may be swept up or collected in plastic drop cloths and disposed of as trash.
- Chemical paint stripping residue and chips and dust from marine paints or paints containing lead, mercury or tributyl tin must be disposed of as hazardous wastes. Lead based paint removal requires a state-certified contractor.
- When stripping or cleaning building exteriors with high-pressure water, block storm drains. Direct wash water onto a dirt area and space into soil. Or, check with the local wastewater treatment authority to find out if you can collect (pump or vacuum) building cleaning water and dispose to the sanitary sewer. Sampling of the water may be required to assist the wastewater treatment authority in making its decision.
- Recycle/Reuse Leftover Paints Whenever Possible.
- Recycle or donate excess water-based (latex) paint, or return to supplier.
- Reuse leftover oil-based paint. Dispose of non-recyclable thinners, sludge and unwanted paint, as hazardous waste.
- Unopened cans of paint may be able to be returned to the paint vendor. Check with the vendor regarding its "buy-back" policy.



DETAIL OF INLET SEDIMENT CONTROL DEVICE  
TYPE A - WITHOUT CURB DEFLECTOR

**Environmental**  
Your Complete Source for  
Geosynthetic Solutions

ACF Environmental, Inc.  
2851 Cielway Rd.  
Redwood, Virginia 22224  
(800) 448-3636



Date: 03/09/2023  
Scale: -  
Design: CJ  
Drawn: CJ  
Approved: DP  
Job No: 20190701

Drawing Number:

C3.2

03/09/2023

STANFORD UNIVERSITY  
OAK ROAD  
SANTA CLARA COUNTY  
CALIFORNIA

APPLICANT: STANFORD UNIVERSITY



ROAD: OAK ROAD

COUNTY FILE NO.:











FINAL COLOR AND MATERIAL SHOWN FOR REFERENCE ONLY AND MAY VARY SLIGHTLY PENDING FINAL VENDOR SUBMITTALS

VERTICAL STEEL TUBING OPEN TO AIR




RIGHT SIDE WALL ELEVATION



LEFT SIDE WALL ELEVATION

2  
-

CANOPY ELEVATIONS  
N.T.S.




1  
-

WASH STATION SEWER DRAIN  
N.T.S.



Delivering Reliability

25-SA



- STRUCTURAL NOTES:
- Concrete: 28 Day Compressive Strength  $f'_c = 7000$  psi
  - Rebar: ASTM A-615 Grade 60
  - Mesh: ASTM A-185 Grade 65
  - Design: AG-218-02 Building Code
  - Load: 15-20 Truck Wheel w/ 30S Impact Per AASHTO

- GENERAL NOTES:
- All bottles and wires to be steel
  - Contractor to supply and install all piping & sampling tees
  - Install in All Pipes
  - Fill With Clean Water Prior To "Start-Up" Of System
  - Verify All Blockout Sizes and Locations

FOR CUSTOM APPLICATIONS  
THE FOLLOWING INFORMATION IS NEEDED:  
Top Of Separator Elevation:  
Inlet Pipe Size:  
Inlet Pipe Elevation:  
Outlet Pipe Size:  
Outlet Pipe Elevation:

SCALE: 3/4"=1'-0"

133.1


© 1990-2016 Oldcastle Precast, Inc.

opauburn.com



Delivering Reliability

25-SA OIL WATER SEPARATOR  
100 Gallon Capacity



Non Skid Covers Available  
FOR DETAILS, SEE REVERSE>>  
Items Shown Are Subject To Change Without Notice  
Issue Date: April 2016

133

© 1990-2016 Oldcastle Precast, Inc.

Mailing Address  
PO Box 688  
Auburn, VA 22807

Phone: 800-892-1038  
Fax: 540-735-1201  
Email: opauburn@oldcastle.com

opauburn.com



03/09/2023

Stanford University  
1720 N. First Street  
Suite 600  
Stanford, CA 94305  
(408) 462-9100  
www.bkf.com

APPLICANT: STANFORD UNIVERSITY

ROAD: OAK ROAD

COUNTY FILE NO.:

BKF ENGINEERS  
1720 N. FIRST STREET  
SUITE 600  
STANFORD, CA 94305  
(408) 462-9100  
www.bkf.com



OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
CONSTRUCTION DETAILS

CALIFORNIA

SANTA CLARA COUNTY

STANFORD

Revisions

No.

Date 03/09/2023

Scale:

Design: CU

Drawn: CU

Approved: DP

Job No: 20190701

Drawing Number:

C4.1

OF





**OAK ROAD VEHICLE WASH STATION  
STANFORD UNIVERSITY  
CONSTRUCTION SITE LOGISTICS PLAN**

STANFORD

## Revisions

No.

Date: 03/09/

Drawing Number:

## C5.0

OF

1. THE BAY AREA QUALITY MANAGEMENT DISTRICT (BAAQMD) HAS IDENTIFIED A SET OF FEASIBLE PM10 CONTROL MEASURES FOR ALL CONSTRUCTION ACTIVITIES. THESE CONTROL MEASURES, AS PREVIOUSLY REQUIRED IN PROGRAM THE EIR, SHALL BE ADHERED TO DURING ALL CONSTRUCTION ACTIVITIES.

- A. WATER ALL ACTIVE CONSTRUCTION AREA AT LEAST TWICE DAILY.
- B. COVER ALL TRUCKS HAULING SOIL, SAND AND OTHER LOOSE MATERIALS OR REQUIRE ALL TRUCKS TO MAINTAIN AT LEAST TWO FEET OF FREEBOARD.
- C. PAVE, APPLY WATER THREE TIMES DAILY, OR APPLY (NON-TOXIC) SOIL STABILIZERS ON ALL UNPAVED ACCESS ROADS, PARKING AREAS AND STAGING AREAS AT CONSTRUCTION SITES.
- D. SWEEP DAILY (WITH WATER SWEEPERS) ALL PAVED ACCESS ROADS, PARKING AREAS, AND STAGING AREAS AT CONSTRUCTION SITES.
- E. SWEEP STREETS DAILY (WITH WATER SWEEPERS) IF VISIBLE SOIL MATERIALS IS CARRIED ONTO ADJACENT PUBLIC STREETS.
- F. HYDROSEED OR APPLY (NON-TOXIC) SOIL STABILIZERS TO INACTIVE CONSTRUCTION AREAS (PREVIOUSLY GRADED AREAS INACTIVE FOR TEN DAYS OR MORE).
- G. ENCLOSE, COVER, WATER TWICE DAILY OR APPLY (NON-TOXIC) SOIL BINDERS TO EXPOSED STOCKPILES (DIRT, SAND).
- H. LIMIT TRAFFIC SPEEDS ON UNPAVED ROADS TO 15 MPH.
- I. INSTALL FIBER ROLLS, SAND BAGS OR OTHER EROSION CONTROL MEASURES TO PREVENT SILT RUNOFF TO PUBLIC ROADWAYS.
- J. RESTAIN VEGETATION IN DISTURBED AREAS AS QUICKLY AS POSSIBLE.
- K. INSTALL WASH BASINS FOR EXITING TRUCKS OR WASH OFF THE TIRES OF TRACKS OF ALL TRUCKS AND EQUIPMENT LEAVING THE SITE; AND
- L. SUSPEND EXCAVATION AND GRADING ACTIVITY WHEN WINDS (INSTANTANEOUS GUSTS) EXCEED 25 MPH.

2. ALL CONSTRUCTION CONTRACTORS SHALL PROPERLY MAINTAIN THE EQUIPMENT WHERE FEASIBLE. USE "CLEAN FUEL" EQUIPMENT AND EMISSIONS CONTROL TECHNOLOGY (E.G. CNG FIRED ENGINES, CATALYTIC CONVERTERS, PARTICULATE TRAPS, ETC.). MEASURES TO REDUCE DIESEL EMISSION WOULD BE CONSIDERED FEASIBLE WHEN THEY ARE CAPABLE OF BEING USED ON EQUIPMENT WITHOUT INTERFERING SUBSTANTIALLY WITH EQUIPMENT PERFORMANCE.


CONSTRUCTION PRACTICES SHALL COMPLY WITH THE REQUIREMENTS OF THE COUNTY OF SANTA CLARA NOISE ORDINANCE AND ARE TO BE MONITORED BY THE GENERAL CONTRACTOR THROUGHOUT THE CONSTRUCTION PROCESS. THE GUP REQUIRES THE FOLLOWING MEASURES TO REDUCE OPERATION NOISE DURING CONSTRUCTION:

- A. MECHANICAL EQUIPMENT WITHIN 50 FEET OF A RESIDENCE SHALL BE ACOUSTICALLY ENGINEERED.
- B. THE BUILDING DESIGN SHALL INCORPORATE DESIGN MEASURES TO LOCATE NOISE SOURCES SUCH AS LOADING ZONES, TRASH BINS AND MECHANICAL EQUIPMENT AS FAR AWAY FROM NOISE SENSITIVE RECEPTORS AS POSSIBLE.
- C. ALL OPERATION NOISE SOURCES SHALL COMPLY WITH THE COUNTY NOISE ORDINANCE FOR CONSTRUCTION ACTIVITIES THAT WOULD AFFECT SENSITIVE NOISE RECEPTORS OR CAMPUS OR IN AREAS OF DESIGNATED SENSITIVE RESIDENTIAL IN THE COMMUNITY PLAN. THE CONTRACTOR SHALL BE GIVEN ADVANCED REGULAR SCHEDULE OF CONSTRUCTION ACTIVITY SCHEDULED TO THE POTENTIALLY AFFECTED RESIDENTS.

4. CONTRACTOR TO PROVIDE TREE PROTECTION PER FDG 01 56 39 WHEN WORKING AROUND TREES (WHICH INCLUDES ACTIVITIES SUCH AS CONTRACTOR PARKING AND BREAK AREAS).
5. CONTRACTOR PARKING AND LAYDOWN WILL BE LOCATED WITHIN THE PROJECT BOUNDARY AND IN AREAS SHOWN ON THIS SHEET ALONG OAK ROAD AND SEARSVILLE PARKING LOT.

PRIMARY FIRE ROUTES

————X———— CONSTRUCTION FENCE



03/09/2023

OAK ROAD

PEDESTRIANS WILL BE  
DETOURED TO USE THE  
ACCESSIBLE PATH ON THE  
WEST SIDE OF OAK ROAD

CONTRACTOR PARKING ON  
OAK ROAD (SEE VIEWPORT A)

PEDESTRIANS WILL BE  
DETOURED TO USE THE  
ACCESSIBLE PATH ON THE  
WEST SIDE OF OAK ROAD

TO SEARSVILLE ROAD  
(SEE VIEWPORT B FOR  
CONTRACTOR LAYDOWN AREA IN  
SEARSVILLE ROAD PARKING LOT)

14-555  
PG 8 of 5

**GRAPHIC SCALE**

( IN FEET )  
1 inch = 10 ft.

LAYDOWN AREA, -  
6 PARKING STALLS

OAK ROAD

14-555  
PG&E

**A OAK ROAD LAYDOWN AREA**

GRAPHIC SCALE

( IN FEET )  
1 inch = 40 ft.

LAYDOWN AREA, -  
10 PARKING STALLS

SEARSVILLE ROAD LAYDOWN AREA